

	<b>BALL</b>	<b>WAIST</b>	<b>INSTEP</b>	<b>BALL</b>	<b>WAIST</b>	<b>INSTEP</b>	<b>BALL</b>	<b>WAIST</b>	<b>INSTEP</b>
	<b>B</b>	<b>B</b>	<b>B</b>	<b>D</b>	<b>D</b>	<b>D</b>	<b>EE</b>	<b>EE</b>	<b>EE</b>
<b>4</b>	<b>7 5/8</b>	<b>7 6/8</b>	<b>8 1/8</b>	<b>8 1/8</b>	<b>8 2/8</b>	<b>8 5/8</b>	<b>8 5/8</b>	<b>8 6/8</b>	<b>9 1/8</b>
<b>4.5</b>	<b>7 6/8</b>	<b>7 7/8</b>	<b>8 2/8</b>	<b>8 2/8</b>	<b>8 3/8</b>	<b>8 6/8</b>	<b>8 6/8</b>	<b>8 7/8</b>	<b>9 2/8</b>
<b>5</b>	<b>7 7/8</b>	<b>8</b>	<b>8 3/8</b>	<b>8 3/8</b>	<b>8 4/8</b>	<b>8 7/8</b>	<b>8 7/8</b>	<b>9</b>	<b>9 3/8</b>
<b>5.5</b>	<b>8</b>	<b>8 1/8</b>	<b>8 4/8</b>	<b>8 4/8</b>	<b>8 5/8</b>	<b>9</b>	<b>9</b>	<b>9 1/8</b>	<b>9 4/8</b>
<b>6</b>	<b>8 1/8</b>	<b>8 2/8</b>	<b>8 5/8</b>	<b>8 5/8</b>	<b>8 6/8</b>	<b>9 1/8</b>	<b>9 1/8</b>	<b>9 2/8</b>	<b>9 5/8</b>
<b>6.5</b>	<b>8 2/8</b>	<b>8 3/8</b>	<b>8 6/8</b>	<b>8 6/8</b>	<b>8 7/8</b>	<b>9 2/8</b>	<b>9 2/8</b>	<b>9 3/8</b>	<b>9 6/8</b>
<b>7</b>	<b>8 3/8</b>	<b>8 4/8</b>	<b>8 7/8</b>	<b>8 7/8</b>	<b>9</b>	<b>9 3/8</b>	<b>9 3/8</b>	<b>9 4/8</b>	<b>9 7/8</b>
<b>7.5</b>	<b>8 4/8</b>	<b>8 5/8</b>	<b>9</b>	<b>9</b>	<b>9 1/8</b>	<b>9 4/8</b>	<b>9 4/8</b>	<b>9 5/8</b>	<b>10</b>
<b>8</b>	<b>8 5/8</b>	<b>8 6/8</b>	<b>9 1/8</b>	<b>9 1/8</b>	<b>9 2/8</b>	<b>9 5/8</b>	<b>9 5/8</b>	<b>9 6/8</b>	<b>10 1/8</b>
<b>8.5</b>	<b>8 6/8</b>	<b>8 7/8</b>	<b>9 2/8</b>	<b>9 2/8</b>	<b>9 3/8</b>	<b>9 6/8</b>	<b>9 6/8</b>	<b>9 7/8</b>	<b>10 2/8</b>
<b>9</b>	<b>8 7/8</b>	<b>9</b>	<b>9 3/8</b>	<b>9 3/8</b>	<b>9 4/8</b>	<b>9 7/8</b>	<b>9 7/8</b>	<b>10</b>	<b>10 3/8</b>
<b>9.5</b>	<b>9</b>	<b>9 1/8</b>	<b>9 4/8</b>	<b>9 4/8</b>	<b>9 5/8</b>	<b>10</b>	<b>10</b>	<b>10 1/8</b>	<b>10 4/8</b>
<b>10</b>	<b>9 1/8</b>	<b>9 2/8</b>	<b>9 5/8</b>	<b>9 5/8</b>	<b>9 6/8</b>	<b>10 1/8</b>	<b>10 1/8</b>	<b>10 2/8</b>	<b>10 5/8</b>
<b>10.5</b>	<b>9 2/8</b>	<b>9 3/8</b>	<b>9 6/8</b>	<b>9 6/8</b>	<b>9 7/8</b>	<b>10 2/8</b>	<b>10 2/8</b>	<b>10 3/8</b>	<b>10 6/8</b>
<b>11</b>	<b>9 3/8</b>	<b>9 4/8</b>	<b>9 7/8</b>	<b>9 7/8</b>	<b>10</b>	<b>10 3/8</b>	<b>10 3/8</b>	<b>10 4/8</b>	<b>10 7/8</b>
<b>11.5</b>	<b>9 4/8</b>	<b>9 5/8</b>	<b>10</b>	<b>10</b>	<b>10 1/8</b>	<b>10 4/8</b>	<b>10 4/8</b>	<b>10 5/8</b>	<b>11</b>
<b>12</b>	<b>9 5/8</b>	<b>9 6/8</b>	<b>10 1/8</b>	<b>10 1/8</b>	<b>10 2/8</b>	<b>10 5/8</b>	<b>10 5/8</b>	<b>10 6/8</b>	<b>11 1/8</b>
<b>12.5</b>	<b>9 6/8</b>	<b>9 7/8</b>	<b>10 2/8</b>	<b>10 2/8</b>	<b>10 3/8</b>	<b>10 6/8</b>	<b>10 6/8</b>	<b>10 7/8</b>	<b>11 2/8</b>
<b>13</b>	<b>9 7/8</b>	<b>10</b>	<b>10 3/8</b>	<b>10 3/8</b>	<b>10 4/8</b>	<b>10 7/8</b>	<b>10 7/8</b>	<b>11</b>	<b>11 3/8</b>